




DRAG RACING BRAKE
SYSTEM INSTALLATION
INSTRUCTIONS

001-0224

FRONT, SN95

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	16-0217, 94-04 MUSTANG SN-95 F1, 10.75	BRACKET, SN-95, 10.75 RTR, F1, LH, RH	1
2	.3125-18 HEX BOLT, TABBED LOCKWASHER ASSY	5/16"-18 X .75 HEX BOLT AND LOCKWASHER ASSEMBLY, 5 PER BAG	5
3	11-B9782, 11-B9781, 11-B9780	M12-1.75 X 40MM SHCS, M12 LOCK WASHER, M12 FLAT WASHER.	2
4	012-0010, .375x24 THREADED INSERT	3/8"-24 THREADED INSERT, INSTALLED IN BRACKET	2
5	002-044SSP	F1 DR-1, 1.75 BORE, .312 RTR, #85 PADS	1
6	11B9897, 11-B9913, 11B9879	3/8-24 X 1" SHCS, LOCK WASHER, FLAT WASHER	2
7	204-0210 REV E, Mustang SN-95, DRAG HAT.	SN-95 DRAG HAT	1
8	3-107531255625	ROTOR, 10.75 X .310, 5 ON 6.25 BC	1



001-0224, SN-95, F1, 10.75
TBM Brakes
Brake Man, LLC
638 Calle Plano
Camarillo, California 93012

- Remove the existing brake components
- Ensure the hub and spindle are clean and free of debris
- Mount the bracket to the spindle using the M12 x 1.75 SHCS, lock washer, and flat washer
- Scuff the pad swept area of the rotor with a rotor hone or 80 grit sandpaper. This allows the pad to seat to the rotor during break in.
- Lay the hat bowl side up and place the flat side of rotor on the hat.

- Apply blue Loctite to the 5/16-18 hex bolts, fasten the rotor to the hats with the bolts and tabbed washers. Torque to 15 ft-lbs. Bend both tabs on the washers.
- Slide hat and rotor assembly onto hub.
- Slide the caliper over the rotor and mount it to the bracket. Snug the 3/8-24 bolts, lock washer and washer. Check for proper radial and horizontal clearance between the rotor and the caliper.
- Insert the brake pads and cotter pins, and hold the pads against the caliper housing. Spin the rotor assembly to check for contact between the rotor and brake pads. The F1 is a zero drag caliper and there should be no contact between the rotor and pads.
- If there is pad to rotor contact, determine which side is causing the interference. Shim the caliper or the bracket as needed using the supplied shim kit to center the caliper over the rotor for zero drag.
- Verify the pad material is sitting in the proper location in relation to top of the rotor [flush +/- .07"]
- Go back and tighten the caliper mounting hardware
- Connect the brake lines check for interference with any suspension or driveline components
- Bleed the entire brake system and verify proper caliper operation and release

Break-In

- All of our brake pads are pre-cured, which extends life and compound stability, and eliminates complicated bed-in procedure
- Take the vehicle out and verify proper brake operation at low speed before bed-in
- Bring the brakes up to operating temperature and ensure they are properly heated
- *this may require some time and caution on the street
- you will feel the pedal come to you, and the brake torque output increase
- Allow the system to cool and the bed-in is complete
- If you observe material transfer to the rotors [dark streaking on the rotors], the system has not been fully bedded in.

If technical support and information is needed please contact us at 805-987-7867 or info@tbmbrakes.com